MAZDA IMMO OFF EMULATOR

MAZDA 323, 626, PREMACY 2.0 DITD

93C56

In memory 93C56 perform modifications of address 18 to 19 write value 11 11 11 11.

SWITCH SETTING

MAZDA 323, 626, PREMACY 2.0 DITD

93C56

In memory 93C56 perform modifications of address 18 to 19 write value 11 11 11 11.

SWITCH SETTING

MAZDA 1.8 PETROL

CUT OFF

or connecting to the immo box

93C56

In memory 93C56 perform modifications of address 17 to 1D write value 11 00 11 00 11 00 11.

SWITCH SETTING

MAZDA PREMACY, MPV 2.0 PETROL

CUT OFF

or connecting to the immo box

93C56

In memory 93C56 perform modifications of address 17 to 1D write value 11 00 11 00 11 00 11.

SWITCH SETTING

MAZDA DEMIO 1.3 PETROL

CUT OFF

or connecting to the immo box

In memory 93C56 perform modifications of address 17 to 1D write value 11 00 11 00 11 00 11.

SWITCH SETTING

MAZDA DEMIO 1.3 PETROL

CUT OFF

or connecting to the immo box

93C56

In memory 93C56 perform modifications of address 17 to 1D write value 11 00 11 00 11 00 11.

SWITCH SETTING

MAZDA EEC-V

For memory modifications please contact our support Skype- ecu-service-support or support@ecu-service.info

SWITCH SETTING

MAZDA MX5

Disconnect immo box

SWITCH SETTING

In memory 93C56 perform modifications of address 17 to 1D write value 11 00 11 00 11 00 11.

MAZDA MX5

BP6M

Disconnect immo box

SWITCH SETTING

In memory 93C56 perform modifications of address 17 to 1D write value 11 00 11 00 11 00 11.

EXAMPLES OF CHANGES

ECU RF4W, RF3F	ECU FPG6, FPD9, B33N, B35J
FOR EMULATOR	FOR EMULATOR
ORIGINAL FILE	ORIGINAL FILE